

SERVICING YOUR WILLIAMS™ FURNACE

GETTING READY FOR WINTER - LIGHTING THE PILOT

MONTEREY TOP VENT FURNACE

NATURAL GAS MODELS

2509622A


3509622A

PROPANE GAS MODELS

2509621A

3509621A

1. This appliance has a pilot which may be lit by hand. When lighting the pilot, follow these instructions exactly.
2. **BEFORE LIGHTING** smell around the appliance area for gas. Be sure to smell next to the floor because some gases are heavier than air and will settle on the floor.
3. Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, don't try to repair it, call a qualified service technician. Force or attempts to repair may result in a fire or explosion.
4. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.
5. **WHAT TO DO IF YOU SMELL GAS**
 - Do not try to light any appliance or strike a match.
 - Do not touch any electrical switch; do not use any phone or cell phone in your building.
 - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
6. Set the thermostat to lowest setting.
7. If applicable, turn off all electric power to the appliance.
8. Open control access panel.
9. Push in gas control knob slightly and turn clockwise to "OFF".
10. Wait five (5) minutes to clear out any gas, then smell for gas, including near the floor. If you then smell gas, STOP! Follow step 5 above in the safety information above. If you don't smell gas, go to the next step.
11. Loosen wing nut and open the pilot observation door (if equipped).
12. To find the pilot, follow metal tube from the gas control. The pilot is mounted on the side of the burner.
13. Turn knob on the gas control counterclockwise to "PILOT".
14. Push in the control knob all the way and hold in. Immediately light the pilot. Continue to hold the control knob in for about one (1) minute after the pilot is lit. Release the knob and the pilot flame will pop back up. The pilot should remain lit. If it goes out, repeat Steps 9 through 14.
 - If knob does not pop up when released, stop and immediately call your service technician or gas supplier.
 - If the pilot will not stay lit after several tries, turn the gas control knob "OFF" and call your service technician or gas supplier.
15. Close pilot observation door, tighten wing nut (if equipped).
16. Turn gas control knob counterclockwise to "ON".
17. Close control access panel.
18. Turn on all electric power to the appliance (if applicable).
19. Set thermostat to desired setting.



WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life. **IMPORTANT:** Keep burner and control compartment clean.